

HOW TO: JACOPO WALL LIGHT



1

Fix the metal bracket on the wall



2

Fix the threaded rod on the canopy using the toothed washer and the nut



2.1

The threaded rod should be out long enough



3

Insert the cable through the rod



4

Mount the ceiling cap on the metal bracket




5

Don't forget to connect the wall cables to the lamp cable



6

Place the shade glass on the canopy



7

Fix it thanks to the brass plate and the two long screws



8

Add-on the socket base on the threaded rod
Screw the small built-in screw



9

Connect the cables



10

Add the last piece of the socket