HOW TO : TOTO

ROTOR DC



Contents :

- Terrazzo front panel
- Painted metal profile
- Red fixing bolts
- Cable, lamp holder, switch and plug



1- Drill holes into the wall using the metal profile as a template. Use the universal wall plugs provided



2- Begin fastening the profile using the screws provided, positioning them by hand from the inside



3- Use a fairly narrow Phillips screwdriver to fully tighten the screws through the front openings



4- Insert the lamp holder through the designated hole, leaving the lower ring in place, then screw on the upper ring



5- Insert the light bulb



6- Position the front panel in front of the profile, aligning the holes



7- Hand-tighten the bolts to secure the panel in place